

Setup/Configuration for Series 300 Unisys Terminals

1. Turn the terminal on. To configure a terminal, one of the following will invoke the configuration mode:
 - (a) Hold down the **[Ctrl]** key and press the **[Select]** key.
 - (b) Hold down the **[SHIFT]** key and press the **[Select]** key. (Unisys terminals purchased approximately August 2004 or later tend to use Shift Select to invoke the configuration mode.)

Consult your Terminal Installation and Operations Guide for more information. Once the configuration mode is invoked, the screen displays a series of menus or “folders” that contain various configuration parameters and options.

2. To set the terminal back to the factory defaults, type **“F”** for the **“Function”** folder. Arrow down to **“Factory Default”** and press **[Enter]**. At the **“OK”** prompt, press **[Enter]**. This will set the terminal to the original factory configuration.
3. Type **“U”** to get to the **“User”** folder. **“Banner Message”** should be highlighted. Press **[Enter]**. Turn the **[Caps Lock]** on and type in the message: **“TAG-N-TRAK.”** Down arrow to **“Exit”** and press **[Enter]**.
4. Down arrow to **“Key Click”**, then right arrow to the submenu. Up arrow to **“Off”**, then press **[Enter]**.
5. Down arrow to **“Key Repeat”** and press **[Enter]**. This turns that option off. The box is empty when the option is off. To “turn on” key repeat, the box should be marked.
6. Down arrow to **“Screen Saver”** right arrow to the submenu, select **“60 min”**, press **[Enter]**.
7. Down arrow to **“Warning Bell”**, then right arrow to the submenu. Select **“High”**, then press **[Enter]**.
8. Type **“E”** to get to the **“Emulation”** folder. Right arrow over to the submenu, then select **“WYSE 60”**. Press **[Enter]**.
9. Type **“D”** to get to the **“Display”** folder. Down arrow to **“Status Line”**, then right arrow to the submenu. Up arrow to **“Extended”**, then press **[Enter]**.
10. Type **“C”** to get to the **“Comms”** folder. Down arrow to **“Com1 Port”**. Right arrow to the submenu. **“Baud Rate”** should be highlighted. Right arrow to the next submenu, up arrow to **“19200”**, then press **[Enter]**.
11. Type **“F”** to get to the **“Function”** folder. Down arrow to **“Save All”** and press **[Enter]**. At the **“OK”** prompt, press **[Enter]**. Up arrow to **“Exit”** and press **[Enter]**.
12. If your terminal is properly hooked up to the concentrator, when you exit the Setup, you should be able to press **[Enter]** and get a login.